

DOOR LOCK ADJUSTMENT - KEG COOLER HIGH

If problems* occur with the doors on the cabinet, there are a couple of adjustments that can be made:

1 - Adjust the lock bracket sideways by loosening the two screws and move the bracket until it lines up with the lock wheel in the handle.

2 - Adjust the depth of the locking plate depth by loosening the small screw and adjusting the depth until the door securely locks in a closed position.

- *
- Difficulties when opening/closing the doors
 - Doors doesn't stay closed
 - When closing one pair of doors, the other pair opens

